


2

Secure panel clips

With the tray upside down, secure a panel clip to each of the wooden blocks on the underside of the tray, using the screws supplied. It is recommended that a small hole is pre-drilled as a lead for the screws. Please Note: Do not use a Power Tool for screwing the screws in to the wooden blocks.



3

Recess Upstand into wall


Place tray the right way up. Once the tray is ready to be fitted you can add the self adhesive tiling upstand if required. Carefully apply self adhesive upstand to the relevant tray edges.

NB. It is important that the tray is perfectly clean and free of grease and dust etc. Also ensure that the upstand is firmly seated along the top of the tray.

Once the upstand is attached you may have to trim the upstand left over to the edge of the tray.

It is also recommended that a small bead of silicone is applied to the top radii of the tray and to any joint.

Using the top edge of the upstand as a guide, draw a line on the walls. Remove wall material below line so inside edge of upstand is flush with the outer face of the wall. (This is particularly important towards the - front of the tray where it joins the wall).



4

Locate tray into position

Place tray into position and level the two sides closest to wall. Adjust the remaining innermost leg assemblies to the required height.

Fit the front panel and check gap between panel bottom and the floor is correct.

Cut down end panel to required length and fit.

Adjust legs if needed, ensuring tray remains level.

Ensure protective film has been removed from upstands and waste areas before final fix.

(Please Note! If using 50mm Low Level Tray Panel, ensure that self levelling compound is used under Tray.)

5


Fit waste pipe and front panel

Fit waste pipe.

Clip panel into position. It may be necessary to cut out a small section of panel lip at floor level to avoid interference with support leg feet.

Place the hair trap and removable waste cover in to position on the fitted waste.

If you are fitting the waste directly to a soil stack, please also use a soil stack vent eg McAlpine VP3 or equivalent alternative.



METROPOLITAN™

Live your life love your shower

**1400 x 800
& 1200 x 800
Straight Slider with
Side Panel
& Straight Slider in
Alcove Tray Fitting
Instructions**

Metropolitan Shower Company, Boston Street, Nelson, Lancashire, BB9 0JA
Tel. 01282 606070 Fax 01282 606065

Document No. D639 Issue 2 30.01.2007

METROPOLITAN™

1400x800 & 1200x800 STRAIGHT SLIDER WITH SIDE PANEL & STRAIGHT SLIDER IN ALCOVE TRAY FITTING INSTRUCTIONS

READ INSTRUCTIONS BEFORE INSTALLATION


IMPORTANT PLEASE CHECK THAT

- There are no electrical cables or pipework behind the surface where drilling is required to fix the enclosure.
- The wall to which the enclosure is to be fitted is reasonably flat and that the shower base is level and stable.
- There are no discernible visible defects. Claims for returns will not be accepted for visible defect found after installation.
- The shower base is adequately sealed to the adjacent wall before the enclosure is fitted. Correct sealing is essential - please follow the instructions.
- The appropriate fixings are obtained if you are not fitting the enclosure to a masonry type wall.
- Your guarantee is validated by the completion and return of the guarantee card, details of which are essential when calling our technical department.
- A non caustic based cleaning agent must be used when cleaning this product.
- It is recommended that any lime-scale is regularly removed by cleaning.

IT IS ADVISABLE TO SEEK ASSISTANCE WHEN FITTING THIS PRODUCT

PRODUCT DIMENSIONS FOR ENCLOSURES WITH SIDE PANEL & ALCOVE

(Refer to outer packaging for product details)



Product	Dimension A (Min-Max)	Dimension B (Min-Max)
1400 with Side Panel	1382 - 1405mm	780 - 803mm
1200 with Side Panel	1182 - 1205mm	780 - 803mm
1400 In Alcove	1360 - 1406mm	780 - 803mm
1200 In Alcove	1160 - 1206mm	780 - 803mm
1400 In Alcove (After Tiling)	1361 - 1401mm	780 - 803mm
1200 In Alcove (After Tiling)	1161 - 1201mm	780 - 803mm

1400x800 & 1200x800 STRAIGHT SLIDER TRAY FITTING INSTRUCTIONS FOR STRAIGHT SLIDER WITH SIDE PANEL & STRAIGHT SLIDER IN ALCOVE ENCLOSURES (50mm & 150mm Access Panels)

Please read these fitting instructions before installation, as incorrect fitting will invalidate the guarantee


Important! Please check that;

- Only natural silicone sealant is used. Any other type of sealant can damage the tray.
- If a floor covering is to be laid under the front panel the height of the tray is adjusted accordingly.
- Prior to installing the tray, remove all packaging and carefully inspect for surface imperfections or damage.
- The site is big enough for tray and subsequent enclosure.
- Floor and walls are reasonably flat and level.

SHOWER TRAY PACK CONTENTS

Shower Tray	1	Large Plastic Legs (L)	7
50 mm Front Panel	1	Panel Clips	6 (4 In Alcove)
150 mm Front Panel	1	Drill Point Screws	24
Leg Sockets (S)	13	Chipboard Screws	40 (36 In Alcove)
Small Plastic Legs (S)	6	Slimline Waste Unit	1
Short Plastic Legs (Sh)	7	Guarantee Card	1
		Tile Upstand	1

Figure 1: Tray Leg Positions for Straight Slider with Side Panel & Alcove



1 Fit adjustable feet

Identify leg type and position, dependant on height of access panel chosen (Figure 1). Secure plastic leg sockets into the suggested positions using the screws provided. Use the fully threaded screws for the sockets that are positioned on to the chipboard areas and drill point screws on encapsulated base board areas (if using a power drill set at a low torque setting). Identify the correct size leg shanks (Figure 1) location and drive fully home into the mounting sockets. The sockets are to be secured on to the chipboard pads in each corner of the tray and centre front and rear, also on to the encapsulated base board as indicated. Fit Waste as per instructions.

